

Printer Compatibility List

Here is a list of printers that can work with the network enclosure

Epson						
ActionLaser 1100		EPL-5900PS	LP-8200C	PictureMate Deluxe	PM 730C	Stylus Color 800
ActionLaser II		EPL-6100	LP-8300C	SQ 1170	PM 740C	Stylus Color 850
ActionPrinter 3250		EPL-6100PS	LP-8300F	Stylus	PM 750C	Stylus Color 860
AcuLaser C1900		EPL-7100	LP-8400F	Stylus 800	Stylus C60	Stylus Color 880
AcuLaser C1900PS		EPL-N1600	LP-8500C	Stylus C 43 SX*	Stylus C61	Stylus Color 900
AcuLaser C2000		EPL-N1600PS	LP-8600	Stylus C20	Stylus C62	Stylus Color 980
AcuLaser C2000PS		EPL-N2050	LP-8600F	Stylus C20SX	Stylus C70	Stylus CX3900*
AcuLaser C4000		EPL-N2050+	LP-8700	Stylus C20UX	Stylus C70 plus*	Stylus CX4900*
AcuLaser C4000PS		EPL-N2050PS	LP-8800C	Stylus C40	Stylus C80	Stylus CX5200
AcuLaser C4100		EPL-N2050PS+	LP-8900	Stylus C40SX	Stylus C82	Stylus Color
AcuLaser C4100PS		EPL-N2120	LP-9000B	PM 760C	Stylus CX1500	Stylus Color 8 3
AcuLaser C8500		EPL-N2500	LP-9000C	PM 770C	Stylus CX3100	Stylus Color 400
AcuLaser C8500PS		EPL-N2500PS	LP-9100	PM 780C	Stylus CX3200	Stylus Color 440
AcuLaser C8600		EPL-N2750	LP-9200B	PM 790PT	Stylus C40UX	Stylus Color 460
AcuLaser C8600PS		EPL-N2750PS	LP-9200C	PM 800C	Stylus C41	Stylus Color 480
AcuLaser C9100		ESC/P Dot Matrix Printer*	LP-9300	PM 820C	Stylus C41SX	Stylus Color 500
C88+		L-1000	LP-9400	PM 850PT	Stylus C41UX	Stylus Color 580
CL 700		LP 8000	LP-9500C	PM 880C	Stylus C42	Stylus Color 600
CL 750		LP-1800	LP-9600	PM 2000C	Stylus C42SX	Stylus Color 640
Dot Matrix		LP-1900	LP-9600S	PM 2200C	Stylus C42UX	Stylus Color 660
E 100		LP-2000	LP-9800C	PM 3000C	Stylus C43	Stylus Color 670
EM 900C		LP-2200	LP-S4500	PM 3300C	Stylus C43SX	Stylus Color 680
EM 900CN		LP-2400	LP-S6500	PM 3500C	Stylus C43UX	Stylus Color 1160
EM 930C		LP-2500	LP-xx00	PM 3700C	Stylus C44	Stylus Color 1500
EM 930CN		LP-3000	LQ-24	PM 7000C	Stylus C44SX	Stylus Color 1520
EPL-5200		LP-3000C	LQ-500	PictureMate	Stylus C44UX	Stylus Color 3000
EPL-5200+		LP-7000	LQ-550*	MC 7000	Stylus C45	Stylus Color I
EPL-5700PS		LP-7000G	LQ-570+	MJ 930C	Stylus C46	Stylus Color PRO
EPL-5800		LP-7500	LQ-850	MJ 6000C	Stylus C48	Stylus D78*
EPL-5800PS		LP-7700	LQ-1050*	MJ 8000C	Stylus Color 740	Stylus DX4050*
EPL-5900		LP-7900	LQ-1170*	MachJet	Stylus Color 740 i*	Stylus Photo
EPL-5900L		LP-8000C	LQ-2550	P 950A*	Stylus Color 760	Stylus Photo 700
EPL-5900P*		LP-8100	LX-1050	PM 700C	Stylus Color 777	Stylus Photo 720
HP						
2000C		DesignJet ColorPro CAD	DeskJet 880C	DeskJet 9600	LaserJet 2430	PSC 370
2500C		DeskJet	DeskJet 882C	DeskJet 9800	LaserJet 3050	PSC 380
2500CM		DeskJet 200	DeskJet 890C	DeskJet F370*	LaserJet 3052	PSC 500
2563		DeskJet 310	DeskJet 895C	DeskJet Plus	LaserJet 3055	PSC 750
Business Inkjet 1000		DeskJet 320	DeskJet 916C	DeskJet Portable	LaserJet 3300 MFP	PSC 750xi
Business Inkjet 1100		DeskJet 340C	DeskJet 920C	Deskjet D1360*	LaserJet 3310 MFP	PSC 1500
Business Inkjet 1200		DeskJet 400	DeskJet 948C	DeskJet 930C	LaserJet 3320 MFP	PSC 1510
Business Inkjet 2200		DeskJet 450	DeskJet 950C	DeskJet 932C	LaserJet 3320N MFP	PSC 1600
Business Inkjet 2230		DeskJet 460	DeskJet 952C	DeskJet 933C	LaserJet 3390	PSC 2110
Business Inkjet 2250		DeskJet 500	DeskJet 955C	DeskJet 934C	LaserJet 3392	PSC 2150
Business Inkjet 2250TN		DeskJet 500C	DeskJet 957C	DeskJet 935C	LaserJet 4000	PSC 2170
Business Inkjet 2280		DeskJet 505J Plus	DeskJet 959C	DeskJet 940C	LaserJet 4050	PSC 2175
Business Inkjet 2300		DeskJet 510	DeskJet 960C	Deskjet D2360*	LaserJet 4100	PSC 2210
Business Inkjet 2600		DeskJet 540C	DeskJet 970C	HL-5050*	LaserJet 4200	PSC 2300
Business Inkjet 2800		DeskJet 550C	DeskJet 975C	LaserJet	LaserJet 4240	PSC 2350
Business Inkjet 3000		DeskJet 600	DeskJet 980C	LaserJet 2	LaserJet 4250	PSC 2355*
Color Inkjet Printer CP1160		DeskJet 610C	DeskJet 990C	LaserJet 2 w/PS	LaserJet 4300	PSC 2400
Color Inkjet Printer CP1700		DeskJet 610CL	DeskJet 995C	LaserJet 2P	LaserJet 4345 mfp	PSC 2410*
Color LaserJet 5		DeskJet 612C	DeskJet 1000C	LaserJet 2P Plus	LaserJet 4350	PSC 2410v*
Color LaserJet 5M		DeskJet 630C	DeskJet 1100C	LaserJet 3	LaserJet 5000	PSC 2500
Color LaserJet 2500		DeskJet 632C	DeskJet 1120C	LaserJet 3D	LaserJet 5100	PSC 2510 photosmart
Color LaserJet 2550		DeskJet 640C	DeskJet 1125C	LaserJet 3P w/ PCL	LaserJet 5200	PaintJet
Color LaserJet 2550L*		DeskJet 648C	DeskJet 1180C*	LaserJet 3P w/PS	LaserJet 5200L	PaintJet XL
Color LaserJet 2605		DeskJet 656C	DeskJet 1200C	LaserJet 4	LaserJet 8000	PaintJet XL300
Color LaserJet 2700		DeskJet 660C	DeskJet 1220C	LaserJet 4 Plus	LaserJet 8100	PhotoSmart 140
Color LaserJet 2800		DeskJet 670C	DeskJet 1280	LaserJet 4L	LaserJet 8150	PhotoSmart 240
Color LaserJet 3000		DeskJet 670TV	DeskJet 1600C	LaserJet 4M	LaserJet 9000	PhotoSmart 320
Color LaserJet 3500		DeskJet 672C	DeskJet 1600CM	LaserJet 4M Plus*	LaserJet 9000 MFP	PhotoSmart 330
Color LaserJet 3550		DeskJet 680C	DeskJet 3547*	LaserJet 4ML	LaserJet 9040	PhotoSmart 370
Color LaserJet 3600		DeskJet 682C	DeskJet 3810	LaserJet 4MP*	LaserJet 9040 MFP	PhotoSmart 380
Color LaserJet 3700		DeskJet 690C	DeskJet 3816	LaserJet 4P	LaserJet 9050	PhotoSmart 420
Color LaserJet 3800		DeskJet 692C	DeskJet 3820	LaserJet 4Si	LaserJet 9050 MFP	PhotoSmart 470
Color LaserJet 4500		DeskJet 693C	DeskJet 3822	LaserJet 4V	LaserJet 9055 MFP	PhotoSmart 2570
Color LaserJet 4550		DeskJet 694C	DeskJet 5150	LaserJet 4V/4LJ Pro	LaserJet 9065 MFP	PhotoSmart 2575*
Color LaserJet 4600		DeskJet 695C	DeskJet 5158	LaserJet 5	LaserJet D1320*	PhotoSmart 2600
Color LaserJet 4610		DeskJet 697C	DeskJet 5160	LaserJet 5L	LaserJet M3027 MFP	PhotoSmart 2700
Color LaserJet 4650		DeskJet 710C	DeskJet 5440	LaserJet 5M	LaserJet M3035 MFP	PhotoSmart 3100
Color LaserJet 4700		DeskJet 712C	DeskJet 5550	LaserJet 5MP	LaserJet M4345 MFP	PhotoSmart 3140*
Color LaserJet 4730 MFP		DeskJet 720C	DeskJet 5550C*	LaserJet 5P	LaserJet M5025 MFP	PhotoSmart 3200
Color LaserJet 5000		DeskJet 722C	DeskJet 5551	LaserJet 5Si	LaserJet M5035 MFP	PhotoSmart 3300
Color LaserJet 5500		DeskJet 810C	DeskJet 5650	LaserJet 6	LaserJet P2015	PhotoSmart 3310*
Color LaserJet 5550		DeskJet 812C	DeskJet 5652	LaserJet 6L	LaserJet P3004	PhotoSmart 7150
Color LaserJet 8500		DeskJet 815C	DeskJet 5670	LaserJet 6MP	LaserJet P3005	PhotoSmart 7260
Color LaserJet 8550GN		DeskJet 816C	DeskJet 5740	LaserJet Plus	LaserJet 6P	PhotoSmart 7268
Color LaserJet 9500		DeskJet 820C	DeskJet 5850	LaserJet 1022	Mopier 240	PhotoSmart 7345
Color LaserJet CM1015		DeskJet 825C	DeskJet 5940	LaserJet 1100	Mopier 320	PhotoSmart 7350
Color LaserJet CM1017		DeskJet 830C	DeskJet 6122	LaserJet 1100A	OfficeJet J5700	PhotoSmart 7400
Color LaserJet CP4005		DeskJet 832C	DeskJet 6127	LaserJet 1160	OfficeJet Pro K550	PhotoSmart 7550
Color deskjet 3500*		DeskJet 840C	DeskJet 6520	LaserJet 1200	OfficeJet Pro K850	PhotoSmart 7660
ColorLaserJet 9500 MFP		DeskJet 841C	DeskJet 6540	LaserJet 1220	OfficeJet Pro K5300	PhotoSmart 7760
DesignJet 230		DeskJet 842C	DeskJet 6600	LaserJet 2100	OfficeJet Pro K5400	PhotoSmart 7800
DesignJet 430		DeskJet 843C	DeskJet 6800	LaserJet 2100M	OfficeJet Pro L7300	PhotoSmart 7960
DesignJet 700		DeskJet 845C	DeskJet 6840	LaserJet 2200	OfficeJet Pro L7500	PhotoSmart 8000
DesignJet 2500CP		DeskJet 850C	DeskJet 6940	LaserJet 2300	OfficeJet Pro L7600	PhotoSmart 8100
DesignJet 3500CP		DeskJet 855C	DeskJet 6980	LaserJet 2410	OfficeJet Pro L7700	PhotoSmart 8200
DesignJet 5500ps		DeskJet 870C	DeskJet 9300	LaserJet 2420	PCL 6/PCL XL Printer*	PhotoSmart 8400

